



## LG C6 REAR TOW HOOK



### Parts Inventory:

1. Tow hook

## **Instructions:**

### **Prep:**

Un-pack all of your items and inspect for any damage. Be sure to report anything wrong as soon as you receive your package.

### **Install**

You will find it easier to lift the back of the car slightly either on a lift or on jack stands just enough to get your hands under the car and around the rear mufflers.

You will need to remove the two center muffler hanger bolts at the back of the car for the install. Depending on which model of exhaust you have on your car you may find it necessary to remove the outer bolts as well as removing the vac. line going to the bi-modal exhaust systems to install your hook. You will locate the tow hook between the muffler hangers and then re-install the bolts. Make sure to use loctite on the bolts when going back on the car. If you had to un-hook your vac. lines, make sure to re-attach them before sitting the car back on the ground.



Sergio De La Torre  
President LG Motorsports



LG Motorsports is not responsible for any improper install, modification to product, or any changes made by installer to product. Any welding or modification will void any product warrantee. LG Motorsports or the dealer is not liable for any loss, damage, or injury due to the direct or indirect use of this product. These components are intended for off-road use only and are not intended for use on street legal, pollution controlled vehicles.